

#### INSTRUCTION MANUAL





# CONTENTS

Read all instructions and warnings before using this product. Keep this manual for future reference.

NIOSH CAUTIONS & LIMITATIONS	3
INTRODUCTION	4
RESPIRATOR COMPONENT CONCEPT	5
WARNINGS	6
RESPIRATOR OPERATION	8
SPECIAL OR CRITICAL USERS INSTRUCTIONS - BREATHING AIR PRESSURE TABLE	9
RESPIRATOR USE / LENSES	10
SETTING UP	12
DOFFING YOUR HELMET / INSPECTION, CLEANING AND STORAGE	14
PARTS AND ACCESSORIES	18

**RPB Safety Global Headquarters** 2807 Samoset Rd, Royal Oak, MI 48073, USA. T: 1-866-494-4599 F: 1-866-494-4509 E: sales.us@rpbsafety.com www.rpbsafety.com

**RPB Safety Asia Pacific Headquarters** 652 Halswell Junction Road, Hornby South 8042 New Zealand. T: +64-3-357-1761 F: +64-3-357-1763 E: sales.nz@rpbsafety.com www.rpbsafety.com

RPB<sup>®</sup>, and advancing your safety are registered trademarks of RPB<sup>®</sup> Safety.

For technical assistance contact our Customer Service Department	Form #: RPB37	
on 1-866-494-4599 or email: customerservice@rpbsafety.com	Rev: 8	







**RPB** Safety

F. 1 866 494 4509



T. 1 866 494 4599

E. info@rpbsafety.com

TYPE CE, CONTINUOUS FLOW, SUPPLIED-AIR RESPIRATOR THESE RESPIRATORS ARE APPROVED ONLY IN THE FOLLOWING CONFIGURATIONS

				R	E٩	SP	IR	AT	0	R (	CC	DM	P	٥N	١E	N٦	٢S						
		M	Alternate Helmets	Alternate	Flow Regulator	and Belt	Alternate Cape	,	Alterr Dis	nate conr	Quic nect	k	,	Alterr	nate I	Hose	S	Breathing Air Tube	Alternate Visor	Alternate	Lenses	Head Gear	Cautions and Limitations2
TC -	Protection1	D E L	02-803	NV2016	2015	03-501	02-813	NV2025	NV2024	NV2032	NV2034	NV2037	NV2027	NV2028	NV2029	NV2035	NV2036	NV2021	02-804	02-810	02-811	02-809	
19C-417	SA/CF/SB	ASTRO	х	х		х	х	х	х	х			х	х	х			х	х	х	х	х	ABCDEJMNOS
19C-423	SA/CF/SB	ASTRO			х		х				х	х				х	х	Х	х	х	х	х	ABCDEJMNOS

#### 1. PROTECTION

CF - Continuous Flow SA - Supplied Air SB - Supplied Air Abrasive Blast

#### 2. CAUTIONS AND LIMITATIONS

- A Not for use in atmospheres containing less than 19.5% oxygen.
- B Not for use in atmospheres immediately dangerous to life or health.
- C Do not exceed maximum use concentrations established by regulatory standards.
- D Air-line respirators can be used only when the respirators are supplied with respirable air meeting the requirements of CGA G-7.1 Grade D or higher quality.
- E Use only the pressure ranges and hose lengths specified in the User's Instructions.
- J Failure to use and maintain this product properly could result in injury or death.
- All approved respirators shall be selected, fitted, used and maintained in accordance with MSHA, OSHA, and other applicable regulations.
- N Never substitute, modify, and, or omit parts. Use only exact replacement parts in the configuration specified by the manufacturer.
- O Refer to user instruction and/or maintenance manuals for information about use and maintenance of these respirators.
- S Special or critical User's Instructions and/or specific use limitations apply. Refer to User's Instructions before donning.

# INTRODUCTION

The RPB® ASTRO SUPPLIED - AIR RESPIRATOR TYPE CE is specifically designed for use during Abrasive Blasting. The ASTRO has been designed for use in atmospheres NOT IMMEDIATELY DANGEROUS TO LIFE OR HEALTH, and from which a user can escape without the aid of the respirator, or that do not exceed concentrations allowed by OSHA, EPA or NIOSH regulations and recommendations.

The RPB® ASTRO is Approved by NIOSH (TC-19C-417, 19C-423 TYPE CE to provide respiratory protection in abrasive blasting and type CE painting applications. The cape is designed to protect the wearer's upper body from rebounding abrasive.

# **RESPIRATOR COMPONENT CONCEPT**

The RPB® ASTRO SUPPLIED AIR RESPIRATOR consists of three main components: RESPIRATOR HELMET ASSEMBLY, BREATHING TUBE ASSEMBLY, and AIR SUPPLY HOSE illustrated in Fig1.1. All three components must be present and properly assembled to constitute a complete NIOSH approved Respirator.



**!WARNING!** Failure to use genuine parts and components that are part of the NIOSH approved respirator assembly will void the approval of the entire respirator assembly.

## **!WARNINGS!**

- Do not use this respirator until you have been trained in the respirators use, maintenance and limitations by a qualified individual (appointed by your employer) who has extensive knowledge of the RPB® ASTRO Respirator.
- Before using this respirator ensure your employer has determined that airborne contaminant concentrations do not exceed those allowed by applicable OSHA, EPA or NIOSH regulations and recommendations for continuous-flow supplied air respirators. Federal law requires that the employer measures and monitors airborne contaminant levels in the work area,
- **3.** DO NOT wear this respirator if any of the following conditions exist:
  - Atmosphere is immediately dangerous to your life or health.
  - You CAN NOT escape without the aid of the respirator.
  - Atmosphere contains less than 19.5% oxygen.
  - Work area is poorly ventilated.
  - Contaminants are in excess of regulations or recommendations.
  - Radiation exists in the work area, or materials are Radioactive.
- 4. Do not modify or alter this respirator.

Use only NIOSH approved RPB<sup>®</sup> ASTRO components and replacement parts. The use of non approved parts voids the NIOSH approval of the entire respirator assembly.

- Inspect all components of the respirator daily for signs of damage or wear and tear that may reduce the level of protection originally provided.
- DO NOT use abrasives containing silica, lead, arsenic or sharp glass particles

   use of abrasives containing these elements could result in serious Injury or death.
- DO NOT wear this respirator until you have passed a complete physical exam including a lung X-ray conducted by qualified medical personnel.
- Improper use of this respirator may cause injury or death. Improper use may also cause life threatening delayed lung diseases such as silicosis, pneumoconiosis or asbestosis.
- This respirator, when properly fitted and used, significantly reduces but does not completely eliminate the breathing of contaminates by the respirator wearer.
- 10. BE CERTAIN your employer has determined that the breathing air source providas at least Grade D

breathable air. The respirator must be supplied with clean filtered breathing air at all times.

- 11. DO NOT connect the respirator's air supply hose to nitrogen, toxic gases, inert gases, or other unbreathable non Grade D air sources. Check the air source before using the respirator. Failure to connect the supply hose to the proper air source could result in serious injury or death.
- 12. DO NOT use this respirator in poorly ventilated areas or confined spaces. Ensure the area is well ventilated and that the contaminant concentrations are below those recommended for this respirator. Follow all procedures for confined space entry, operation and exit as defined in applicable regulations and standards.

#### 13. LEAVE WORK AREA IMMEDIATELY IF:

- Any respirator componant becomes damaged.
- Airflow stops or slows down.
- Breathing becomes difficult.
- You become dizzy, nauseous, too hot, too cold or ill.
- Vision is impaired.
- **14.** DO NOT wear this respirator if the ambient usage temperature is below

-10°C or above +60°C.

# **RESPIRATOR OPERATION**

#### **AIR QUALITY**

This respirator must be supplied with clean breathable air, Grade D or better, at all times. The RPB<sup>®</sup> ASTRO does not purify air or filter contaminants.

Breathable air must be supplied to the point of attachment of the RPB Safety air supply hose. Supplied breathing air must at least meet the requirements for Type 1 gaseous air described in the Compressed Gas Association Commodity Specifications G.7.1 (Grade D or higher)

#### **AIR SOURCE**

Locate the air source in a clean air environment, always use a filter on the inlet of your air source. Do not park vehicles beside your air inlet as this will cause carbon monoxide to be drawn into your air supply. Use suitable aftercoolers / dryers with filters and carbon monoxide alarms to assure clean breathable air is supplied at all times. The air should be regularly sampled to ensure that it meets Grade D requirements.

#### **AIR SUPPLY HOSE AND FITTINGS**

RPB<sup>®</sup> Safety air supply hoses must be used between the point of attachment and the respirator breathing air connection at the wearer's belt. RPB<sup>®</sup> Safety quick disconnect fittings must be used to connect the hose lengths together. The hose sections must be within the approved length and the amount of sections must be within the number specified in the Breathing Air Pressure Table on page 9.

#### **BREATHING AIR PRESSURE**

The air pressure must be continually monitored at the point of attachment while the air is flowing to the respirator. Air pressure must be read from a reliable pressure gauge whilst the respirator has air flowing through it.

**!WARNING!** Failure to supply the respirator with the minimum required pressure at the point of attachment for the length of air supply hose used could result in contaminants being inhaled as the pressure in the helmet may become negative due to peak inhalation flow when working at very high work rates

# SPECIAL OR CRITICAL USERS INSTRUCTIONS

#### **BREATHING AIR PRESSURE TABLE**

This table lists air pressure ranges needed to provide the RPB<sup>®</sup> ASTRO with the volume of air that falls within the required range of 6-15cfm or 170-425 lts/min according to U.S government regulations.

1. AIR SOURCE	2. BREATHING TUBE ASSEMBLY AND FLOW CONTROL DEVICES	3. AIR SUPPLY HOSE	4. SUPPLY HOSE LENGTH	5. MAX NUMBER OF SECTIONS	6. PRESSURE RANGE (PSIG AIR)
Portable or Stationary Compressor	NV2021/ NV2016 Flow Control Valve Assembly	NV2028(25ft) NV2029 (50ft) NV2027(100ft)	25 50 100 150 200 250 300	1 2 3 4 5 6	26- 27 27 - 28 30 - 31 33 - 34 36 - 37 38 - 39 41 - 43
Low Pressure Compressor or Air Pump	NV2021/ NV2015 Constant Flow Valve Assembly	NV2035 (50ft) NV2036 (100ft)	50 100 150 200 250 300	1 1 2 2 3 3 3	7 - 8 8 - 9 10 - 11 11 - 12 12 - 13 14 - 15
Portable or Stationary Compressor	NV2021/ 03-501 Climate Control Tube Assembly	NV2028 (25ft) NV2029 (50ft) NV2027 (100ft)	25 50 100 150 200 250 300	1 2 3 4 5 6	50 - 80 55 - 85 60 - 95 65 - 95 70 - 100 75 - 100 85 - 100

#### BEFORE USING THIS RESPIRATOR MAKE SURE YOU UNDERSTAND THE TABLE BELOW.

Set the air pressure at the point of attachment within the range specified in column 6 for your breathing tube assembly, hose length and amount of hose sections. Make sure air is flowing through your respirator when setting the pressure.

Refer to 03-501 C40 Climate Control Tube Instruction for pressure ranges specified for use with the RPB<sup>®</sup> ASTRO.

# **!WARNING!** RESPIRATORS MUST BE SUPPLIED WITH RESPIRABLE AIR MEETING THE REQUIREMENTS OF CGA G-7.1 GRADE D OR HIGHER QUALITY.



# **RESPIRATOR USE**

#### AIRFLOW CONTROL VALVE



Air flowing into the helmet is controlled using the regulator as shown in Fig 2.1 and 2.2.



**NOTE:** The minimum of 170 Vmin should be flowing through the helmet when the regulator is in the closed position as in Fig 2.2 and the pressure set in accordance with the table on page 8.

#### LENSES



#### **Inner Lens**

Place one end into the gasket first, then slowly roll the gasket over the sides of the lens, working towards the other end.



#### **Outer Lens** Place the lens into the face frame and push past the locating ribs.



#### NOTE

Always make sure that a RPB® Safety inner lens is securely fitted into the window frame gasket. Proceed fitting lenses as Fig 3.1, Fig 3.2, Fig 3.3.

Fold the visor across the front of the helmet and lock the strap tightly over the side cleat.

## **SETTING UP**



#### Head Harness

To adjust the head harness first unclip the locating pegs, then slide the band in or out to the desired size. Note: slide inwards to reduce the size. Once the desired size is obtained, clip the locating pegs back together.

#### **Putting the Helmet in Place**

Hold the helmet in front of you, holding the inner bib collar open. Lift the helmet and place it on your head making sure the head harness fits securely.



## **SETTING UP**



First screw on the breathing hose in a clockwise direction onto the helmet.



Screw the loose running nut in a clockwise direction onto the flow control device (2016).



Take the quick dis-connect fitting on the Air Supply Hose and push onto the tail of the Flow Control Device.



Connect the Air Supply Hose Tail to the point of attachment supplying Grade D air.



#### FITTING THE CAPE AND BELT



Once the helmet is fitting comfortably on your head, straighten the cape down at the front and back.



Place the Flow Control Device to your desired hip pocket.



Now bring both buckles together at the front and push them until you hear a click. Pull the tab to tension the belt to your requirement.



Now the helmet is fully fitted and the belt tightened, adjust the airflow into the helmet with the Flow Control Device adjustment barrel see Fig 2.1 on Page 9. Again check the air pressure at the source to make sure it is still in accordance with Table 1.1 on page 9.

# **DOFFING YOUR HELMET**

To remove the helmet, first exit the working area and reverse procedures in Respirator Use. **!WARNING!** NEVER remove your helmet when in the working area.

# **INSPECTION, CLEANING AND STORAGE**

The RPB® ASTRO Supplied Air Respirator has a limited service life, therefore a regular inspection and replacement programme must be conducted. Certain parts such as lenses must be replaced frequently.

All components of the respirator assembly should be inspected for damage or wear and tear before use. Replace worn or damaged parts immediately. USE ONLY RPB® SAFETY ASTRO PARTS. Refer to the parts list for the correct part numbers. **!WARNING!** DO NOT CLEAN RESPIRATOR WITH VOLATILE CHEMICALS.

#### **REMOVING THE CAPE**



First remove the cape cover band to reveal the eight press studs. The cape can then easily be removed by undoing the four press studs.

#### **INSPECTING THE HELMET**



Having removed the cape, wipe out the inside of the helmet with a soft cloth and mild detergent. Check the inside for cracks in the shell and damage to the air inlet.

#### **INNER LENS AND GASKET**



Make sure the window frame gasket is securely fitted in the helmet with no cracks or tears in the seal. Check that the inner lens is correctly fitted into the gasket. When necessary replace lenses as in Figures 3.1 and 3.2.

#### **BREATHING TUBE ASSEMBLY**

Inspect the breathing tube for cracks, tears or excessive wear. Check that the fittings are secured into the cuffs tightly, not allowing any air leaks.

Replace the hose as soon as any signs of damage or excessive wear become evident. Do not remove the foam that is inside the breathing tube as this is a critical component.

**!WARNING!** Air leaks will cause a drop in air flow through the respirator helmet resulting in less protection from contaminants.

#### **AIR SUPPLY HOSE**

The air supply hoses should be inspected for:

- 1. Cuts or tears
- 2. Cracks or signs of perishing
- 3. Blisters or weak points
- Abrasive wear the hose or are not worn, remove any dirt inside couplings with a duster gun.
- 5. Ferrules firmly crimped in place
- 6. Quick disconnect couplers do not move in.

# USE ONLY HOSES NIOSH APPROVED FOR USE WITH THIS RESPIRATOR.

#### STORAGE

After the respirator components have been cleaned and inspected, place them in a plastic bag or an airtight container. Store the respirator parts away from excessive heat, dust, cold, moisture or harmful chemicals.

After use hang the respirator up by the hand strap, this will help keep the inside of the helmet free of contaminants.



## PARTS AND ACCESSORIES

VISOR AND LENSES Fid

Figure 10.1



AIR SUPPLY HOSES

Figure 10.2



#### BREATHING TUBE & FLOW CONTROL DEVICES Figure 10.3



**RESPIRATOR CAPES** Figure 10.4



#### NOTES



#### NOTES

# **OTHER PRODUCTS**

#### **AIRLINE FILTRATION**

The RPB® RADEX AIRLINE FILTER<sup>™</sup> offers increased capacity, versatility and filtration. This optional equipment combines the versatility of either floor or wall mounting with increased filtration capacity, enabling customization to meet worker's needs and working environments.

#### **AIR TEMPERATURE CONTROL**

The RPB® 4000-01 Cool Air Tube cools compressed breathing air coming into the respirator by up to 30°F while the RPB® 4000-20 Hot Air Tube will heat the compressed air by up to 30°F. These maximize worker comfort and increase productivity in hot or cold climates.

#### **AIR QUALITY MONITORING**

The RPB® RADEX CO MONITOR<sup>™</sup> helps ensure worker safety with a unique traceability feature that monitors and records carbon monoxide levels, and temperature. This data that provides certainty of monitor functioning and can be stored for up to two years allowing analysis of plant and field air quality.

# rpb

### 1866 494 4599 www.rpbsafety.com



1773

#### SOSOOI